



As of January 2011, U.S. EPA regulations require the application of a permanently applied label near the fuel tank fill port for diesel driven equipment. This label is to state: ULTRA LOW SULFUR FUEL ONLY

Northern Lights is providing this label for application to the fuel inlet of the fuel supply tank for each engine or generator set. This is to be applied by the installer of the engine or gen set, or by the manufacturer of the equipment that the engine or gen set is installed in. The location of the label must be in clear site of personnel that refill the supply tank.



Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

#### **Northern Lights**

4420 14th Avenue N.W. Seattle, WA 98107 Tel: (206) 789-3880 Fax: (206) 782-5455

Copyright ©2013\5 Northern Lights, Inc. All rights reserved. Northern Lights ™ and the Northern Lights logo are trademarks of Northern Lights, Inc.

Printed in U.S.A. PART NO.: ONL673L4 8/15



# **OPERATOR'S MANUAL**

# for Model NL673L4 and NL673L4E

Read this operator's manual thoroughly before starting to operate your equipment. This manual contains information you will need to run and service your new unit.

# **Table of Contents**

INTRODUCTION	2	SERVICING	
Models Included	2	Lubrication - General	15
Model Numbers	2	Checking Oil	16
Serial Numbers	2	Oil Changes	16
		Changing Oil Filter	
WARRANTY	3	Air Filter	
		V-Belts	17
SAFETY RULES3	- 7	Valve Clearances	17
		Fuels - General	18
LOCK OUT / TAG OUT PROCEDURES	8	Fuel Filters	18
		Bleeding the Fuel System	19
COMPONENT LOCATIONS		Injector Service	
Industrial Generator	10	Injection Pump	
		Cooling System - General	
CONTROL PANEL		Cooling System Flushing	
S-1B Control Panel	.11	Clean Radiator	
		Electrical System - General	22
OPERATING PROCEDURES		Glow Plugs	
Break-in Period	12	Booster Batteries	
Before Starting	12	Battery Care	23
Starting	12	Winterizing / Out-of-Service	
Operating		Generator End	
Stopping			
Shutdowns and Alarms		TROUBLESHOOTING	
Spare Parts	13	Electrical	28
		Lamp Codes	
SERVICING SCHEDULE CHART	14	Engine	
		WIDING DIAGDAMS	

#### **Proprietary Information**

This publication is the property of Northern Lights, Inc.

It may not be reproduced in whole or in part without the written permission of Northern Lights, Inc.

© Northern Lights, Inc. All rights reserved. Litho U.S.A. Publication number ONL673L4 8/15

#### Introduction

Servicing of industrial generator sets presents unique problems. In many cases these generators are far from a repair facility. Generators cannot be compared to the servicing of automobiles, trucks or even farm equipment. Failures often occur in remote areas far from competent assistance. Generators can be taxed far more severely than auto or truck engines; therefore, maintenance schedules must be adhered to more strictly.

Failures begin with minor problems that are overlooked and become amplified when not corrected during routine maintenance.

As operator, it is your obligation to learn about your equipment and its proper maintenance. This is not a comprehensive technical service manual. Nor will it make the reader into an expert mechanic. Its aim is to aid you in maintaining your unit properly.

### **Unit Identification**


#### **MODELS INCLUDED**

This manual covers the operating instructions for:


NL673L4 & NL673L4E industrial generator sets.

### **Model Numbers**

Model numbers give the unit's application, block model, aspiration, and RPM:



### **Serial Numbers**



Your set has three serial numbers: an engine number stamped on the block, a generator plate, and a generator set plate.

Use the serial number on the generator set plate when ordering parts or in correspondence. The generator set plate is found on the service side of the generator and resembles the drawing in Figure 1.

Figure 1: Generator set serial number plate.

## Warranty

A warranty registration certificate is supplied with your set. It entitles the original purchaser of our equipment to a warranty covering material or assembly faults. The extent of coverage is described in the Limited Warranty Statement. We recommend that you study the statement carefully. **NOTE:** If the warranty is to apply, the servicing instructions outlined in this manual must be followed. If further information is needed, please contact an authorized dealer or the factory.

## Safety Rules



NOTICE: Accident reports show that careless use of engines causes a high percentage of accidents. You can avoid accidents by observing these safety rules. Study these rules carefully and enforce them on the job.

#### IMPORTANT SAFETY INSTRUCTIONS.

Electromagnetic equipment, including generator sets and their accessories, can cause bodily harm and life threatening injuries when improperly installed, operated or maintained. To prevent accidents be aware of potential dangers and act safely.



READ AND FOLLOW ALL SAFETY INSTRUCTIONS IN THIS MANUAL, PRIOR TO THE INSTALLATION OF ANY GENERATOR SET OR ACCESSORY. KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

### **Recognize Safety Symbols and Instructions**

In addition to the information found in this section, this operator's manual uses three different signal words to outline potential dangers of a specific nature.



DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.



WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION indicates a hazardous situation which, **CAUTION** if not avoided, could result in minor or moderate

#### **Follow All Safety Instructions**

Carefully read and understand all safety messages in this manual and on your machine's safety signs. Keep signs in good and clean condition. Replace missing or damaged signs. Be



sure new equipment components and repair parts include the current safety signs. For replacement signs, proper placement of safety signs or clarification on any safety issue, consult your Northern Lights dealer or the factory.

There can be additional safety information contained

on parts and components from outside suppliers that is not reproduced in this manual. Consult the suppliers for additional safety information.

Learn how to operate the machine and how to use the controls properly. Only trained personnel should operate machines, or work on or around them.

Keep you machine in proper working condition. UNAUTHORIZED MODIFICATIONS TO THE MACHINERY MAY IMPAIR ITS FUNCTION AND SAFETY PARAMETERS.

### **Prevent Bypass and Accidental Starting**

# **! WARNING**

Do not start engine by shorting across start terminal. Engine will start if normal circuitry is bypassed. creating a hazard by runaway machinery.



Start engine only from operator's station.

#### **Handle Fuel Safely - Avoid Flames**

# **A WARNING**

Diesel is highly flammable and should be treated with care at all times. Do not refuel while smoking or when near sparks or open flame.

ALWAYS STOP ENGINE BEFORE FUELING MACHINE. Always fill portable fuel tank outdoors. Never fuel a hot engine.



Prevent accidental discharge of starting fluids by storing all cans in a cool, safe place, away from sparks or open flame. Store with cap securely on container. Never incinerate or puncture a fuel container.

Prevent fires by keeping machine clean of accumulated trash, grease and debris. Always clean any spilled fuel as swiftly as possible. Do not store oily rags, which can ignite and burn spontaneously.

Be prepared if a fire starts. Keep a first aid kit and fire extinguisher handy. Keep emergency contact numbers for fire department, doctors, ambulance and hospital near the telephone.

### **Service Machines Safely**

# **ADANGER**

Do not wear a necktie, scarf, necklace, rings or other jewelry, or any loose clothing when working near moving



parts. Tie long hair behind your head. If any of these items get caught in moving machinery, severe injury or death could result.

Check for any loose electrical connections or faulty wiring.

Look completely around engine to make sure that everything is clear before starting.

#### **Wear Protective Clothing**

# **A WARNING**

To prevent catching anything in moving machinery, always wear close fitting clothes and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause hearing

loss or impairment.

Wear suitable authorized hearing protection, such as earmuffs or plugs to protect against loud noises



Operating equipment requires the full attention of the operator. Do not use radio or music headphones while operating machinery.

#### **Practice Safe Maintenance**





Understand all service procedures before starting work. Keep area clean and dry. Never lubricate, service, or adjust machine while it is in operation.

Keep hands, feet and clothing away from powerdriven equipment. When shutting down an engine, disengage all power and operator controls. Allow the engine to cool completely before beginning any service work.

Securely support any machinery elements that must be raised for service work with support or lifting machinery specifically intended for that purpose.

Keep all parts in good conditions and properly installed. Fix damage immediately. Replace any worn or broken parts. Remove any build up of grease, oil or debris.

Disconnect battery ground cable (-) before making any adjustments or service work.

## **Stay Clear of Rotating Drivelines**

# **ADANGER**

Entanglement in rotating drivelines can cause serious injury or death. Keep shields in place at all times. Make sure that rotating shields turn freely in pace with the drivelines.

Do not wear loose fitting equipment around rotating drivelines. Stop the engine and make sure that all moving parts have stopped before making any adjustments, connections, or performing any other type of service to the engine or other driven



equipment.

#### **Install all Safety Guards**

# **!** WARNING

Direct contact with rotating fans, belts, pulley and drives can cause serious injury.

Keep all guards in place at all times during engine operation.



Wear close-fitting clothes. Stop the engine and be sure all fans, belts, pulleys and drives are stopped before making adjustments, connections, or cleaning near fans and their components.

Do not allow anything on your person to dangle into or come in contact with a moving fan, belt, pulley or drive. Fans can act as vacuums and pull materials up from below, so avoid that area as well while in service.

### Safe Battery Handling

# **A** WARNING

#### **Prevent Battery Explosions**

Battery gas is highly flammable. Battery explosions can cause severe injury or death. To help

prevent battery explosions, keep sparks, lighted matches and open flame away from the top of battery. When checking battery electrolyte level, use a flashlight.

Never check battery charge by contacting the posts with a metal object. Use a volt-meter or hydrometer.

Frozen batteries may explode if charged. Never charge a battery that has not been allowed to warm to at least  $16^{\circ}$ C ( $60^{\circ}$ F).

Always remove grounded (-) battery clamp first and replace ground clamp last.

Sulfuric acid in battery electrolyte is poisonous and strong enough to burn skin, eat holes into clothing and other materials, and cause blindness if splashed into eyes.

#### To Avoid Hazards:


- Fill batteries only in well-ventilated areas.
- Wear appropriate eye protection and rubber gloves.
- Never use air pressure to clean batteries.
- Wear appropriate ventilation equipment to avoid inhaling fumes when adding electrolyte.
- Do not spill or drip electrolyte.
- Use correct jump-start procedure if required.

## If acid is spilled on skin or in eyes:

- 1. Flush skin with water.
- 2. Apply baking soda or lime to help neutralize acid.
- 3. Flush eyes with water for 15-30 minutes.
- 4. Get medical attention immediately.

If acid is swallowed:

- 1. DO NOT induce vomiting.
- 2. Drink large amounts of water or milk, without exceeding 2 liters (2 quarts)
- 3. Get medical attention immediately



# **1** WARNING

Battery posts, terminals, and related accessories can contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. Wash hands after handling.

### **Handle Chemical Products Safely**

# **1** WARNING

Direct exposure to hazardous chemicals can cause serious injur. Among the potentially hazardous chemicals that may be used with Northern Lights products are lubricants, coolants, paints and adhesives.



All potentially hazardous chemicals come with a Material Data Safety Sheet (MSDS). The MSDS provides specific details on chemical products, including physical hazards, safety procedures and emergency response techniques

Read and understand the MSDS for each chemical before you start any job that includes it. Follow the procedures and use appropriate equipment exactly as recommended.

Contact your Northern Lights dealer or Northern Lights factory for MSDS's used on Northern Lights products.

#### Work in Well Ventilated Areas

# **A** CAUTION

Exhaust fumes from engines contain carbon monoxide and can cause sickness or death. Work in well ventilated areas to avoid prolonged exposure to engine fumes. If it is necessary to run an engine in an enclosed area, route the exhaust fumes out of the area with an approved, leak proof exhaust pipe extension.

### Remove Paint Before Welding or Heating

# **1** WARNING

Hazardous fumes can be generated when paint is heated by welding, soldering or using a torch. To avoid potentially toxic fumes and dust, remove paint before heating.



- Remove paint a minimum of 100 mm (4 in.) from the area that will be affected by heat.
- If paint cannot be removed, wear an approved respirator.
- If you sand or grind paint, use an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers from the area.
- Allow at least 15 minutes for fumes to disperse before welding or heating.

Do not use a chlorinated solvent in an area where welding will occur. Work only in areas that are well ventilated. Dispose of paint and solvent properly.

#### Service Cooling System Safely

# **A** WARNING

Opening a pressurized cooling system can release explosive fluids and causing serious burns. Before opening any pressurized cooling system, make sure the



engine has been shut off. Do not remove a filler cap unless it is cool enough to comfortably grip with bare hands. Slowly loosen cap to relieve pressure before opening fully.

#### **Avoid High Pressure Fluids**

# **1 WARNING**

Relieve pressure prior to disconnecting pressurized lines. Escaping fluid under pressure can penetrate the skin causing



serious injury. Always relieve pressure before disconnecting hydraulic or other pressurized lines. Tighten all connections firmly before re-applying pressure.

If searching for leaks, use a piece of cardboard. Always protect your hands and other body parts from high-pressure fluids.

If an accident occurs, see a doctor immediately. Any high pressure spray injected into the skin must be removed within a few hours to prevent the risk of gangrene or other infection.

### **Avoid Heating Near Pressurized Fluid Lines**

# **1** WARNING

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns and bodily injury. Pressurized lines



can rupture when heat goes beyond the immediate flame area. Do not weld, solder or use a torch or open flame near pressurized lines or other flammable fluids.

#### Do Not Open High-Pressure Fuel System

# **ADANGER**

Many Northern Lights engines use high-pressure fuel injection. High-pressure fluid remaining in fuel lines can cause serious injury. Do not disconnect or attempt any repair of fuel lines, sensors, or other

components between the high-pressure fuel pump and nozzles on engines with high pressure fuel systems.



ONLY AUTHORIZED TECHNICIANS CAN PERFORM REPAIRS ON AN HIGH PRESSURE FUEL INJECTION SYSTEMS.

#### **Avoid Hot Exhaust**





Avoid exposure to and physical contact with hot exhaust gases. Exhaust parts and streams can reach high temperatures during operation, leading to burns or other serious injury.

Cleaning exhaust filters can also lead to exposure to hot exhaust gas and the injury risk associated with it. Avoid exposure to and physical contact with hot exhaust gases when cleaning exhaust filters.

During auto or manual/stationary exhaust filter cleaning operations, the engine will run at elevated temperatures for an extended period of time. Exhaust parts and streams can reach high temperatures during operation, leading to burns or other serious injury.

### **Avoid Harmful Asbestos Dust**

# **1** WARNING

Inhaling asbestos fibers may cause lung cancer. Avoid breathing any dust that may be generated when handling components containing asbestos fibers, including some gaskets.



The asbestos used in these components is usually found in a resin or otherwise sealed. Normal handling of these components is not dangerous, as long as airborne dust containing asbestos is not generated.

Avoid creating dust. Never use compressed air for cleaning. Avoid brushing or grinding materials containing asbestos. When servicing, wear an approved respirator. A special vacuum cleaner is recommended to clean asbestos. If this vacuum is not available, apply a mist of oil or water on the

material containing asbestos. Keep all bystanders away from any area where asbestos dust may be generated.


# **Use Proper Lifting Equipment** and Techniques

# **A WARNING**

Lifting heavy components incorrectly can cause severe injury or damage to machinery. Avoid unbalanced loads. Do not use lifting eyes. Lift the generator set using lifting bars inserted through the lifting holes on the skid. Follow all recommended removal and installation procedures in this and associated Northern Lights manuals.

### **Use Proper Tools**

# **A** CAUTION



Use power tools only to loosen threaded parts and fasteners. For loosening and tightening hardware, always use the correct sized tools.

Do not use US measurement tools on metric fasteners, or vice versa. Use only service parts that meet Northern Lights specifications.

#### Dispose of Waste Properly

# **A** CAUTION

Disposing of waste improperly can threaten the environment and lead to unsafe working conditions. Potentially harmful waste used in Northern Lights equipment can include oil, fuel, coolant, filters and batteries.

Use leakproof containers to drain fluid. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain or into any water source.

## **Lock Out / Tag Out Procedures**

#### Scope

During maintenance, repairs or retooling of a Northern Lights generator set, simply turning the machine off or unplugging it while it is being worked on does not give enough protection to others who are not performing the maintenance or repair. Many serious accidents happen when someone thought the machine was turned off, or all of its energy was safely blocked or released.

#### **General Policy**

# **A** CAUTION

To avoid dangerous or hazardous situations, refrain from any of the following:

- · Removing or bypassing a guard or other safety device
- Placing any part of your body in a position where you could be caught by moving machinery.
- · Cleaning or oiling machinery when in operation.
- Adjusting circuits, chillers, pumps, air handlers, valves, circuit breakers or fans while in operation.
- Working on piping or high pressure systems.

## Lock Out/Tag Out Instructions -Electrical Equipment

# **A WARNING**

Be sure the equipment's ON/OFF switch is in the OFF position and is unplugged from any electrical source before attempting to perform any type of work on the equipment. Obtain an electrical plug cap cover with a lockset. Secure the plug terminal end using the electrical plug lockout cap. Lock the cap and retain the key.

If the equipment is directly wired into an electrical box with a shut off switch, obtain a lock pad and/or the appropriate colored tags and place the lock and tag through the shut off lever. Retain the key until the repair is completed and the machine is safe to start. Be certain the shut off lever is in the OFF position before restarting. NEVER give a lock out key to unauthorized personnel.

If the equipment is directly wired into an electrical box without a shut off switch and lock out capability, then a circuit breaker lock out will be required. Obtain a circuit lock and tag set. Install the lock onto the circuit breaker box. Ensure the unit ON/OFF switch is in the OFF position before restarting.

### Lock Out/Tag Out Instructions -Pneumatic and Hydraulic Equipment

# **1** WARNING

For servicing pneumatic and hydraulic equipment, the following additional procedures must be implemented, following completion of lock out/tag out procedures for the unit to be serviced:

Shut off air, water or supply valves at the equipment to be serviced.

Check the local bleed-off point for completed release of pressurized air, water or oil.

If shutting off of air, water or other material cannot be achieved at the local supply valve, shut off valves further back in the system and re-check the bleed-off point until complete shut-off is achieved.

Affix a DO NOT OPERATE tag to each valve handle that requires shut off. Each DO NOT OPERATE tag must be signed and dated by the authorized technician servicing the equipment.

### Lock Out/Tag Out Instructions -Air Hose Connected Pneumatic Equipment

# **1** WARNING

Equipment connected to the compressed air system through an air hose with a detachable fitting must be shutdown and unplugged. Excess air must be bled prior to removing the air hose, prior to any maintenance or repair activities.

Affix a DO NOT OPERATE tag to the air hose near the detachable fitting. Each DO NOT OPERATE tag must be signed and dated by the authorized technician servicing the equipment. Check that the equipment cannot be operated by activating the ON switch.

#### **Stored Energy**

# **A WARNING**

Immediately after applying Lock Out or Tag Out devices, ensure that all potentially hazardous stored or residual energy is relieved, disconnected, restrained and otherwise rendered safe.

#### **Verification of Isolation**

# **A** CAUTION


Verify the machinery or equipment is actually isolated and de-energized prior to beginning work on a machine or on equipment that has been locked out.

### **Restarting Procedures**

# **A** CAUTION

Follow the procedures below prior to restoring energy:

- Ensure that all machinery or equipment is properly reassembled. Inspect the machinery or equipment to verify non-essential items have been removed.
- Ensure that all personnel are safely outside danger zones. Notify personnel that lock out/tag out devices have been removed and energy will be reapplied.
- Only authorized personnel may remove lock out/tag out devices or notices.



# **Industrial Generator Component Locations** 5 (21) (20) (8) (13)(10) (11 (12 (16) (15 (8) (18) (17 Figures 2-A and B: NL673L4E Service Side and Non-service side

1. Junction Box 2. S-1B Control Panel

3. Air Filter

4. Fuel Filter Vent

5. Lube Oil Fill

6. Injection Pump

7. Coolant Fill

8. Radiator Shroud

9. Dipstick

10. Oil Filter

11. Fuel Lift Pump

12. Secondary Fuel Filter

13. Vibration Mount

14. Warning Light15. Exhaust Outlet

16. Starter

17. Electrical Control Unit

18. Alternator

Engine DC Breaker
 AC Circuit Breaker

21. Voltage Regulator Breaker

22. Fuel Suple & Return Connections

#### **Control Panel**




Figure 3: Series 1-B Generator Control Panel

#### 1. PREHEAT/ SHUTDOWN BYPASS SWITCH

This switch serves two functions:

- 1. Preheats the fuel before beginning the starting process. Press switch for 10-20 seconds before attempting start-up.
- 2. Bypasses the safety shutdown feature during the starting process. Keep switch engaged while starting engine, and for 2 to 3 seconds afterwards, allowing oil pressure to build beyond the shutdown set point.

NOTE: Three position Engine Control switches must be in the RUN position during preheating. Preheat switch must be held in ON position during starting.

#### 2. ENGINE CONTROL SWITCH

To start the engine, hold this switch in the START position until the engine is running.

After the engine starts, release the switch and it will return to RUN position. To stop the engine, hold the switch in the STOP position.

NOTE: The rocker switch is used on Series 1 panels only, and has a light that glows when the set is running.

#### 3. HOUR METER

Keeps track of engine running time.

## **Operating Procedures**

#### **BREAK-IN PERIOD**

- 1. The first 100 hours on a new or reconditioned engine are critical to its life and performance.
- 2. Operate the engine under various conditions, particularly heavy loads with minimal idling, to help set engine components properly.
- 3. Constantly check the engine temperature and oil pressure.
- 4. Oil consumption is greater during break-in as piston rings take time to seat.
- Break-In Oil Changes: Change engine oil and filter at 50 hours. Change oil and filter again at 100 hours (consult Lubricants section for oil recommendation).

#### **BEFORE STARTING**

1. Check the water level by removing the pressure cap from the expansion tank or radiator. In order to give the cooling water an opportunity to expand, the level should be about 1 in. (2.5 cm) below the filler cap sealing surface when the engine is cold.

CAUTION: Use protective clothing and open the filler cap carefully when the engine is warm to prevent burns.



- 2. Check the oil level in the crankcase with the dipstick. The oil level must be in the waffled area on the stick. Never allow the level to go below this area. Always add the same viscosity of oil as is already in the crankcase.
- 3. Check the fuel tank level and open any fuel valves.

NOTE: The battery switch must always be kept ON while the engine is running. If the switch is turned OFF while the engine is running, the battery charging regulator could be ruined.

#### **STARTING**

- Hold the Shutdown Bypass-Preheat switch in the ON position for 10 to 20 seconds before starting a cold engine. Holding the switch too long can burn out the glow plugs.
- 2. While holding the Shutdown Bypass-Preheat switch in the ON position, push the Engine Control switch to the START position.
- 3. As soon as the engine starts, release both switches. Do not crank the starter for more than 10 seconds consecutively. If the engine fails to start with the first attempt, be sure that it has stopped completely (stationary at least 30 seconds) before re-engaging.

#### **OPERATING**

- Check oil pressure often. Oil pressure must be above 15 PSI. Normal coolant temperature is 75 to 90°C (167 to 194°F). Check the AC voltage and frequency. If these deviate from normal levels, shut down the generator set and investigate.
- 2. Let the unit run unloaded for about 10 minutes for a warm-up period.
- 3. Add electrical load.

#### **STOPPING**

- 1. Cool down the engine by operating at low idle speed for 3 minutes.
- 2. Check the engine noise and oil pressure for abnormalities.
- 3. Remove electrical load from the generator set.
- 4. Turn the control switch to off.

# **Operating Procedures**

#### SHUTDOWNS AND ALARMS

- 1. Generator sets have shutdown systems to stop the engine in the event of high water temperature or low oil pressure.
  - Other alarms and shutdowns are available as optional equipment.
  - NOTE: Do not rely on any shutdowns to the exclusion of careful gauge monitoring. Watching your gauges can prevent damage to the unit and dangerous power losses.
- Electronically-controlled generator sets will run at reduced capacity when the Engine Control Unit (ECU) detects a problem with one of its sensors. These problems are indicated by a flashing trouble code on the ECU warning light. For the NL676L4E, see Figure 30 on page 28 for the meaning of different codes.
- 3. Do the following when your warning or shutdown system is activated:
  - a. Check the temperature gauge. If above 230°F (110°C), shut off the engine immediately.
  - b. Use the Trouble Shooting Guide on page 24 to isolate the cause of the overheat.



CAUTION: Do not remove the water fill cap of an overheated engine. Escaping high temperature steam can cause severe burns. Allow the engine to cool and then remove the cap slowly using protective clothing.

- c. Make repairs.
  - Restart your Industrial set after the temperature gauge registers below 225°F (107°C).
- d. Watch the temperature gauge regularly and turn off the unit if the temperature rises above 230°F (110°C) on Industrial sets. Repeat trouble shooting.
- 4. If shutdown is activated and the temperature gauge shows temperature within normal temperature range:
  - a. Check the engine crankcase oil level.
  - b. If the oil level is low, fill with recommended lubricating oil and restart. Watch the oil pressure gauge carefully and shut off the engine if it does not show a normal reading (20-60 PSI) after a few seconds of operation.

- c. If the oil level is normal, DO NOT restart the engine. Call your dealer for assistance.
- 5. If the ECU is indicating a trouble code
  - a. Record the code and shut off the engine.
  - b. Refer to Figure 30 on page 28 and the DC wiring diagram to determine the problem.
  - c. Repair the problem and restart the engine.

#### **SPARE PARTS**

- 1. NLI recommends that you keep the following spare parts on hand for field service. The parts are available from your local Northern Lights dealer.
- 2. All owners should have the following:
  - a. Primary and secondary fuel filter elements
  - b. Oil filters
  - c. Air filter
  - d. Alternator belt
  - e. Thermostat and gaskets
  - f. Glow plug
  - g. Injector and washer
- 3. If your set is operating a long distance from a servicing dealer, add the following:
  - a. Complete set of injectors
  - b. Copper washers for injector change
  - c. Complete set of glow plugs
  - d. Fuel lift pump

# **Servicing Schedule Chart**

The Servicing Schedule Chart below shows the service schedule required for proper maintenance of your generator set. More detailed coverage of each Service Point (SP) is listed on the page noted in the 'page' column.

#### DAILY:

SP1 Check oil level in engineSP5 Check V-belt tensionSP7 Check primary fuel filter

SP13 Check coolant level

SP18 Check electrolyte level in batteries

#### **AFTER FIRST 50 HOURS:**

SP2/3 Change engine oil and filter

SP6 Adjust valves

#### **AFTER FIRST 100 HOURS:**

SP2/3 Change engine oil and filter

#### **EVERY 200 HOURS:**

SERVICE

SP2/3 Change engine oil and filter

SP4 Check air cleaner

SP8 Change primary fuel filter element

SP9 Change secondary fuel filter

SP16 Check radiator filler cap

#### **EVERY 500 HOURS:**

SP11 Check injectors

SP14 Check and flush cooling system

SP19 Check state of charge of batteries

200

1000

2500

500

#### **EVERY 1000 HOURS:**

SP6 Check valve clearances

SP12 Check fuel injection pump

SP16 Check and clean radiator

POINT	PAGE	OPERATION		DAILY	Hours	Hours	Hours	Hours	Hours
		ENGINE:							
SP1	8 & 12	Check oil level		•					
SP2	12	Change engine oil	1) 4)		•	•			
SP3	12	Change lube oil filters	1) 4)		•	•			
SP4	13	Check air cleaner	1) 3) 6)			•			
SP5	13	Check V-belt tension	1) 3)	•					
SP6	13	Check valve clearances						•	
		FUEL SYSTEM:							
SP7	14	Check primary filter (Racor)	2)	•					
SP8	14	Change primary filter element (Racor)	2)				•		
SP9	14	Change secondary fuel filter	1) 2)				•		
SP10	15	Bleed the fuel system	2)						
SP11	17	Check injectors	1) 2) 5)					•	
SP12	17	Check fuel injection pump							•
		COOLING SYSTEM:							
SP13	17	Check coolant level		•					
SP14	18	Check and flush cooling system							•
SP16	18	Check and clean radiator fins						•	
		Check radiator filler cap				•			
		ELECTRICAL SYSTEM:							
SP18	19	Check electrolyte level in batteries	1) 3)	•					
SP19	19	Check condition of batteries with hydrometer	1) 3)			•			
		OUT OF SERVICE:							
SP20	19	Winterizing or out-of-service	2)						

- 1) Perform all maintenance once a year even if hour level has not been reached.
- 2) Whenever necessary.
- 3) More often if necessary.

- 4) After first 50 hours and at 100 hours.
- 5) Clean injection nozzles every 1500 hours.
- 6) Replace element every 1000 hours.



#### **LUBRICATION - GENERAL**

- 1. Use only clean, high quality lubricants stored in clean containers in a protected area.
- 2. These lubricants are acceptable:
  - a. API Service CC/CD/CE single viscosity oils.
  - b. API Service CC/CD/SF multi-viscosity oils.
- 3. Use the proper weight oil for your average operation temperature.

Air Temperature	Single Viscosity	Multi- Viscosity
Above 32°F (0°C)	SAE 30W	SAE 15-40W
-10 to 32°F (-23 to 0°C)	SAE 10W	SAE 10-30W
Below -10°F (-23°C)	SAE 5W	SAE 5-20W

Figure 4: Lube Oils

- 4. Some increase in oil consumption may be expected when SAE 5W and SAE 5-20W oils are used. Check oil level frequently.
- 5. Never put additives or flushing oil in crankcase.

#### SP1. CHECKING OIL LEVEL

 Check the oil level in the crankcase with the dipstick. The oil level must be in the waffled area on the stick. Never allow the level to go below this area. Follow the lubrication recommendations above.

#### SP2. OIL CHANGES

- The set is delivered with special break-in oil.
   Change the engine oil and oil filter after 50 hours of operation. Use Service CC 30 weight oil during the first 100 hours.
- 2. Change the oil and filter again at 100 hours using the oil recommended in Figure 4. After this, change oil and filter every 200 hours.
- 3. During intermittent cold weather operation, change oil every 100 hours or six weeks, whichever comes first
- 4. Change oil at any seasonal change in temperature when a new viscosity of oil is required.
- 5. Change oil when engine is warm.
- 6. Dispose of waste oil in an approved manner.
- 7. Never use a flushing oil.
- 8. Loosen the clamp on the oil change tube. Remove cap. Drain oil. Replace the cap and tube.
- 9. Refill engine with recommended oil.
- 10. Engine capacity with new oil filter is:
  - 3.3 quarts (3.1 liters)

#### SP3. CHANGING LUBE OIL FILTER

- 1. Change the lube oil filter every 200 hours.
- 2. Use a filter wrench to remove old filter. Dispose of filter in approved manner.
- 3. Make sure the gasket from the old filter is removed and discarded. Clean mount face.
- 4. Spread a thin film of engine oil on the rubber gasket on the new filter and screw it on nipple until gasket meets the sealing surface.
- Using hands only no wrench tighten filter one-half turn farther. Overtightening can do damage to filter housing.
- 6. Fill engine with recommended oil. Start engine and check for leakage. Stop engine, wait 3 minutes, and check oil level. Add additional oil if necessary.
- 7. The oil filter part numbers are:

#24-08001 - NL673L2 and NL673L3 #24-02001 - NL673K and NL673L

#### **SP4. AIR CLEANER**

- 1. Inspect air cleaner every 200 hours. In dusty conditions, check more often.
- 2. Industrial sets: the element cannot be cleaned. Replace it when necessary. Part number is: NL673K, L, L2, L3 #24-27301
- 4. NOTE: Make absolutely sure no impurities enter the engine while changing the element. Do NOT run the engine with the air cleaner removed.



- 1. Check the tension and wear on the V-belt daily.
- 2. Use your thumb to press on the belt at the midpoint between the fan pulley and alternator pulley. The tension is correct if the belt can be depressed about 3/16 in. (5 mm).
- 3. If belt needs to be adjusted pivot the alternator (Figure 5) at the alternator mounting bolt by:
  - 1. Loosening the alternator tensioning arm bolt and the alternator mounting bolt.
  - 2. Then pivot the alternator at the mounting bolt toward the engine left or right side as required.
  - 3. Tighten the mounting bolt and the adjusting bolt.
  - 4. Recheck belt tension after tightening bolts and again after running the engine for five minutes at low idle.




Figure 5: Belt Tension




Figure 6: Valve Adjustment

#### **SP6. VALVE CLEARANCES**

- 1. Adjust valve clearance every 1000 hours, or as needed.
- 2. Valve adjustments should be done after the cylinder head bolts have been re-tightened. Engine should be cold and NOT running.
- 3. Watch the valves while turning the engine over by hand. Turn until the inlet valve starts to open and the exhaust valve starts to close (the valves are rocking). Then turn the crankshaft one more full turn and adjust the clearance on both valves for this cylinder.
- 4. Loosen the lock nut and adjust the clearance between the rocker arm and valve guide of both the intake and exhaust valves with the adjustment screw (Figure 6). Clearance on both intake and exhaust valves should be 0.008 in. (0.2 mm).
- 5. Repeat steps 3 and 4 for each cylinder. Each set of valves must be adjusted individually.
- 6. Replace the rocker arm cover. Tighten cover nuts to 5 8 ft/lbs (0.8 2.3 kg/m).

#### **FUELS - GENERAL**

- Use only clean, high quality fuels of the following specifications, as defined by ASTM designation D975 for diesel fuels:
  - a. Use grade no. 2 diesel at ambient temperatures above freezing 32°F (0°C).
  - b. Use grade no. 1 at ambient temperatures below freezing and for all temperatures at an altitude of above 5,500 ft. (1500 meters).
- 2. Use fuel having less that 1% sulphur (preferably less that 0.5%).
- 3. The cetane number should be a minimum of 45.
- 4. DO NOT use these unsuitable grades of fuel:
  - a. Domestic heating oils, all types.
  - b. Class B engine.
  - c. Class D domestic fuels.
  - d. Class E, F, G or H industrial or marine fuels.
  - e. ASTM-D975-60T No. 4-D and higher number fuels.
- 5. Storing fuel:
  - a. Keep dirt, scale, water, and other foreign matter out of fuel.
  - b. Avoid storing fuel for long periods of time.
  - c. Fill the fuel tank at the end of each day's operation. This will reduce condensation.

#### SP7-9. FUEL FILTERS

- 1. Your generator set should have a primary fuel filter installed. We recommend the Racor brand of fuel filter-water separators.
  - a. Check the primary fuel filter daily as recommended by the filter manufacturer.
     Empty the collection bowl as necessary.
  - b. Change the element as often as necessary or every 250 hours.
  - c. If the bowl fills with water, change the primary and secondary element immediately.
- 2. Change secondary fuel filter every 250 hours.
  - a. Remove the spin-on filter by turning it counterclockwise with a filter wrench. Fill the new cartridge with fuel and install it after applying engine oil to gasket surface. Screw on until the gasket surface comes into contact with sealing surface of filter base. Then, tighten it two-thirds of a turn by hand. Do not overtighten.
  - b. The fuel filter part number is: NL673K, L, L2, L3, L4 #24-52020

#### SP10. BLEEDING THE FUEL SYSTEM



CAUTION: Escaping diesel fuel under pressure can penetrate skin causing serious personal injury. Before disconnecting lines be sure to relieve all pressure. Before applying pressure, be sure all connections are tight and lines, pipes and hoses aren't damaged. Fuel escaping from a very small hole can be almost invisible. Use a piece of cardboard or wood, rather than hands, to search for suspected leaks. If injured by escaping fuel, see a doctor at once. Serious infection or reaction can develop if proper medical treatment isn't administered immediately.




Figure 7: 673 Fuel System.

- 1. The fuel system is self-bleeding. However, any system may need manual bleeding when:
  - a. A new fuel filter is installed;
  - b. The engine has run out of fuel;
  - c. The fuel lines, injection pump or any other fuel system component has been removed and installed.
- 2. Loosen bleed screw "A" (Figure 7) on top of the filter. Pump hand primer "B" on fuel lift pump until pure fuel (no bubbles) escapes from bleed screw "A". Tighten bleed screw "A".
- 3. Loosen bleed screw "C". Pump hand primer "B" on fuel lift pump until pure fuel (no bubbles) escapes from bleed screw "A".
- 4. If the engine does not start after the above bleeding process, loosen a fuel line at the injector. Crank the engine until pure fuel escapes, then tighten the connection. Do each line **one at a time.**
- 5. After the engine has started, check for fuel leaks using a piece of cardboard.



Figure 8: Remove delivery line flare nuts.




Figure 9: Remove delivery lines.



Figure 10: Remove return line nuts.




Figure 11: Remove return line.




Figure 12: Unscrew injector.




Figure 13: Remove and replace copper sealing washer.




Figure 14: Reinstall injector. Torque to proper tightness.

#### SP11. INJECTOR SERVICE

Injectors should be checked every 1000 hours.
 Check should be made by a Northern Lights dealer or local injection repair station.



CAUTION: Escaping diesel fuel under pressure can have sufficient force to penetrate the skin causing serious personal injury. If injured by escaping diesel fuel, see a doctor at once.

#### 2. Injector removal:

- a. Clean loose dirt from around the injectors and the fuel lines.
- b. Relieve high pressure in the fuel lines by loosening the delivery line flare nuts at each injector (Figure 8).
- c. Remove delivery lines by disconnecting from injectors and injection pump (Figure 9). Remove all lines as an assembly; do not remove the spacers. Cover the ends of the lines, the injector inlets and injection pump outlets to keep dirt out.
- d. Remove the return line retaining bolts (Figure 10). Remove the return line (Figure 11).
- e. Unscrew and remove the injectors (Figure 12).
   NOTE: Do not use pry bars to remove injectors from cylinder head.
- f. After removing the injectors, discard the copper sealing washers from the injector hole in the head (Figure 13). Cover holes to prevent dirt and debris from entering the cylinders.

#### 3. Injector installation:

- a. Install a new copper sealing washer in each injector hole (Figure 13).
- b. Screw in injector and tighten to 43 or 50 ft/lbs (6 to 7 kgm) (Figure 14).

#### NOTE: Overtightening can damage injector.

- c. Install return line using new copper sealing above and below each connection. Tighten return line retaining bolts to 22 30 ft/lbs.
- d. Install delivery lines. Leave loose at injectors for bleeding.
- e. Pump hand level on fuel pump to fill lines.
   Tighten lines at injectors. Start engine and check for leaks using a piece of paper or cardboard.
   DO NOT use hand to check for leaks.

#### **SP12. INJECTION PUMP**

- Since operating conditions may vary considerably, it
  is difficult to give a definite interval for checking the
  injection pump. But as a rule, pump settings,
  maximum speed, idle speed and exhaust smoke
  should be checked after every 2500 hours of
  operation. Service of the fuel injection pump should
  only be done if checks indicate pump malfunction.
- Black smoke can be an indication of pump malfunction. Before servicing the pump, check other possible causes:
  - a. Check cleanliness of air filter.
  - b. Check valve clearances.
  - c. Clean and check injectors.
- Any repair which involves disassembly of the injection pump must be carried out by specially trained mechanics with the proper tools and test equipment.

NOTE: All warranties on the engine become null and void if the injection pump seals are broken by unauthorized persons.

#### **COOLING SYSTEM - GENERAL**



CAUTION: The cooling water in the engine reaches extremely high temperatures. You must use extreme caution when working on hot engines to avoid burns. Allow the engine to cool before working on the cooling system. Open the filler cap carefully, using protective clothing when the engine is warm.

#### **WATER QUALITY**

 Distilled, deionized, soft water is preferred for use in cooling systems. Bottled distilled water from a food store or water supplier is recommended. Tap water often has a high mineral content. Tap water should NEVER be put in a cooling system unless first tested by a water quality laboratory. <u>Do not</u> use water made by the reverse osmosis method unless it has been PH neutralized.

2. Here are acceptable water quality specifications:

Contaminates	Parts per Million	Grains per Gallon
Maximum Chlorides	40	2.5
Maximum Sulfates	100	5.9
Maximum Dissolved Solids	340	20.0
Maximum Total Hardness	170	10.0
	PH Le	evel 5.5 to 9.0

- 3. If chlorides, sulfates or total dissolved solids are higher than the above given specification, the water must be distilled, demineralized, or deionized before it is used in a cooling system.
- 4. If total hardness is higher than 170 ppm and all other parameters are within the given specifications, the water must be softened before it is used to make coolant solution.

#### SP13. CHECK THE COOLANT LEVEL

- Check the coolant level each day before starting the engine. Check the water level by removing the pressure cap from the radiator.
  - In order to give the cooling water an opportunity to expand, the level should be about 1 in. (2.5 cm) below the filler cap sealing surface when the engine is cold.
- 2. The pressure valve in the filler cap releases when the pressure is approximately 7 PSI (0.5 bar). Use a cap pressure tester to check cap if you suspect it is faulty.

#### SP14. COOLING SYSTEM FLUSHING

- 1. Flush the cooling system every 2500 hours or every 12 months, whichever comes first.
- 2. Industrial sets:
  - Remove radiator cap and open drain cocks on radiator and engine block. Pour clean water into radiator until water coming from radiator is clear of discoloration. Close the radiator drain and continue flushing until water from engine drain is clear. Open all drain cocks and drain completely. Close drain cock and refill with recommended coolant mixture. Clean fins on radiator.
- Coolant Specifications:
   Use 50% water / 50% ethylene glycol antifreeze mix. Antifreeze mixture is recommended as a good year-round coolant.
- 4. Check hoses and connections and repair any leakage.

#### SP16. CLEAN RADIATOR

- 1. Remove debris from radiator fins daily.
- 2. In very dusty applications, clean the radiator with compressed air or steam cleaner every 100 hours. Clean in the reverse direction of the airflow.

#### **ELECTRICAL SYSTEM - GENERAL**

- 1. Never switch battery switch off or break the circuit between the alternator and batteries while the engine is running. Regulator damage can result.
- 2. Do NOT reverse the polarity of battery cables when installing the battery.
- 3. When welding on the unit, disconnect the regulator and battery. Isolate the leads.
- 4. Disconnect the battery cables when servicing the D.C. alternator.
- 5. Never test with a screwdriver, etc., against any terminal to see if it emits sparks.
- 6. Do not polarize the alternator or regulator.
- 7. A D.C. circuit breaker protects your control panel and wiring harness. It is located in the side of the generator junction box.

#### **GLOW PLUGS**

- 1. Each cylinder is supplied with a glow plug which serves to heat the combustion chamber.
- 2. To check the glow plugs, loosen the current carrying flat wire between the plus-poles of the glow plugs (Figure 15). Connect a D.C. test bulb between the plus-pole of the battery and the plus-pole of the glow plug. If the bulb lights up, the glow plug is functioning properly.
- 3. Check all glow plugs and replace any faulty ones.




Figure 15: Glow plugs.

#### **BOOSTER BATTERIES**



CAUTION: Battery gas can explode. Keep all flames and sparks away from batteries.

- Before changing or using booster batteries, check battery electrolyte level. Add distilled water if necessary.
- 2. Booster and main batteries must have the same voltage rating.
- 3. First, connect positive (+) terminal of booster battery to positive (+) terminal of main battery. Then, connect negative (-) terminal of booster battery to ground on the engine block (see Figure 16).
- 4. Remove booster battery after starting engine.
- 5. Sealed batteries: See manufacturer charging and booster instructions.




Figure 16:
Battery connections.

#### SP 18-19. BATTERY CARE

- 1. Check electrolyte level daily. Add distilled water to manufacturer's recommended level.
- Batteries, cables and cable terminals should be checked and cleaned every 100 hours.
   Clean corrosion with a water and baking soda solution. Flush with clean water. Tighten terminals and grease them to inhibit corrosion.
- 3. Check the battery condition with a hydrometer every 250 hours.

#### SP20. WINTERIZING / OUT-OF-SERVICE

- 1. Industrial sets:
  - a. Drain and flush the radiator and cooling system.
     Leave dry or refill with antifreeze-water mixture.
     If refilling, start the engine and run to circulate the antifreeze.
  - b. Fill the fuel tank or add biocide as per manufacturer's instructions.
  - Seal the air cleaner inlet, exhaust opening, crankcase breather pipe, and fuel tank vent with plastic bags and tape.
  - d. Store the set in a dry, protected place. If unit must be stored outside, be sure it is well protected with a cover.
  - e. Change the crankcase oil and filter.
  - f. Loosen the alternator belt.
  - g. Disconnect and clean battery. Remove to warm storage place if possible.
  - h. Clean outside of unit. Paint any scratched or chipped surfaces. Put corrosion preventative on all exposed metal surfaces.

#### **GENERAL**

- 1. A Generator Set includes the engine, the generator, and the control or "J" box (Figure 17).
- 2. The generator and the control or "J" box produce the electrical power.
- Generator excitation is provided by residual magnatism and electrical output voltage is controlled by the automatic voltage regulator (AVR) located in the control box (Figure 19, Item 2).

#### **GENERATOR** (Figure 18)

- 1. Stator Core
- 2. Stator Coil
- 3. End Cover
- 4. Brush
- 5. Ball Bearing
- 6. Slip Ring
- 7. Frame
- 8. Coupling Plate
- 9. Field Coil
- 10. Field Core
- 11. Shaft
- 12. Ventilation Cover

#### **CONTROL BOX** (Figure 19)

- 1. Control Terminal Board
- 2. Automatic Voltage Regulator (AVR)
- 3. 12 Volt DC Circuit Breaker
- 4. AC Circuit Breaker
- 5. AVR Circuit Breaker
- 6. Output Terminal Board




Figure 17: Composition.




Figure 18: Generator Components.




Figure 19: Control Box Components.

#### **CONNECTIONS**

- 1. 120 Volt Output:
  - a. 120 volt output can be selected by connecting the terminals of the control terminal board to 120 (Figure 20).




Figure 20: Control Terminal Board, 120 Volt Output

b. Connect U1 to U2 and V1 to V2 on the output terminal board (Figure 21). Connect 120 volt output leads to terminals U1 and V2.





Figure 21: Output Terminal Board, 120 Volt Output

- 2. 240 Volt Output:
  - a. 240 volt output can be selected by connecting the terminals of the control terminal board to 240 (Figure 22).



*Figure 22:* Control Terminal Board, 240 Volt Output b. Connect U2 to V1 on the output terminal board (Figure 23).




Figure 23: Output Terminal Board, 240 Volt Output

- 3. 120/240 Volt Output
  - a. Connect the control terminal board for 240 volts (Figure 24).




Figure 24: Control Terminal Board, 120/240 Volt Output

 b. Connect U2 and V1 on the output board (Figure 25). Connect output leads to U1 and V2 and neutral lead to V1 (or U2). 240 volt output is available from the leads connected to U1 and V2. The 120 volt load should be divided as equally as possible between two 120 volt circuits.




Figure 25: Output Terminal Board, 120/240 Volt Output

#### **OPERATION**

In order to ensure a long, trouble-free life, the generator must be operated properly and the specified maintenance must be performed.

#### **OPERATING ENVIRONMENT**

Always keep electrical equipment clean. Moisture, salt, dust, and oil will damage the generator. The operating environment must be kept as clean and moisture free as possible.

#### **VENTILATION**

Good ventilation is important for proper generator operation. When installing the generator set, be sure the ambient temperature does not exceed 40°C (104°F) during operation.

#### **MAINTENANCE**

Proper and effective maintenance is required to ensure trouble-free operation. In addition to the above items, the following are required:

- 1. Periodically check all bolts and nuts for proper torque. This is especially true for coupling bolts.
- 2. Be sure to keep the generator area clean and dry.
  - a. Dust and foreign material may reduce the flow of cooling air, reducing heat dissipation and causing the generator to overheat.
  - If electrically conductive debris accumulates on the windings, or if moisture or salt water are absorbed into the windings, the windings may short or ground, reducing voltage output.
  - c. Wiping is the only effective method for removing dust and foreign materials. Use a clean, lint-free piece of cloth.
- If the generator has not been operated for an extended period of time, check the insulation resistance of each stator coil and the rotor. Disconnect the AVR from the generator when performing this test.

#### 4. Voltage Adjustment

- a. If there is some voltage, but it does not build up to rated voltage, voltage adjustment can be made using the "hand trimmer" in the AVR (Figure 26).
- b. The normal voltage setting at no load is 121 volts at 62 Hertz or 242 volts at 62 Hertz.




Figure 26: Hand Trimmer Location on AVR.

- 5. Check the ball bearing in the generator end.
  - a. Listen for unusual noise.
  - Abnormal temperature rise can be noted by discoloration.
  - c. If the bearing is failing, it must be replaced.
  - d. Generator bearing should be replaced by your Northern Lights dealer at 10,000 hours.

#### 6. Check the brushes

- a. The carbon brushes gradually wear with use, so they must be inspected periodically and replaced as necessary.
- b. If the brushes are excessively worn as to expose the pigtail (Figure 27), sparking will occur at the surface of the slip ring, causing surface damage. Therefore, periodic inspection of the brushes is important.
- c. Normally, the brushes will have to be replaced with a new brush assembly within 3,000 hours.




Figure 27: Brush Pigtail.

#### 7. Replacing Brushes

- a. Shut down the generator. Remove four screws and end cover of the generator.
- b. Brush assembly is white plastic with two wires leading to it. It is located at ten o'clock and is held in position by two screws (Figure 28).
   Remove the screws and unplug leads.




Figure 28: Brush Location.

 Attach leads to new brush assembly and install it with the plastic ears towards the front of the generator.

NOTE: Be sure to connect wire J to terminal J, and connect wire K to terminal K.

#### 8. Generator Protection

To protect the generator and AVR from unbalanced loads and over loads, two 20 amp breakers are placed in the output circuit and one 3 amp breaker is placed in the AVR sensing circuit (Figure 29).




Figure 29: Breaker Locations.

- 9. Parts: See Parts Book for complete list
  - a. Bearing

Part #22-68305

b. Brush assembly

Part #22-68304

- 10. Test Specifications: See Wiring Diagram(s)
  - a. Resistance of J-K 16.6 ohm at 20°C (68°F)
  - b. Resistance of A-B 0.25 ohm at 20°C (68°F)
  - c. Resistance of U1-V2 0.56 ohm at 20°C (68°F)
  - d. No load voltage setting 242V or 121V at 62 Hz with cold generator

# DC ELECTRICAL SYSTEM

PROBLEM	POSSIBLE CAUSE	RECOMMENDATION(S)
Battery Will Not Charge	Loose or corroded connections	• Clean and tighten battery connections.
	Sulfated or worn out batteries	<ul><li>Check specific gravity of each battery.</li><li>Check electrolyte level of each battery.</li></ul>
	Loose or defective alternator belt	<ul><li>Adjust belt tension.</li><li>Replace belt.</li></ul>
Starter Inoperative	Check DC circuit breaker	• If the breaker is tripped, reset it.
	Loose or corroded connections	<ul> <li>Clean and tighten loose battery and harness plug connection.</li> </ul>
	Low battery output	<ul><li>Check specific gravity of each battery.</li><li>Check electrolyte level of each battery.</li></ul>
	Defective electrical system ground wire:	• Repair or replace.
Starter Cranks Slowly	Low battery output	<ul><li>Battery is too small.</li><li>Battery cables are too small.</li></ul>
	Check specific gravity of each battery	• Replace battery if necessary.
	Check electrolyte level of each battery	• If low, fill cells with distilled water.
	Crankcase oil too heavy	• Fill with oil of appropriate viscosity.
	Loose or corroded connections	• Clean and tighten loose connections.
Entire Electrical System	Check DC circuit breaker	• If breaker is tripped, reset it.
Does Not Function	Faulty connection	<ul> <li>Clean and tighten battery and harness plug connections.</li> </ul>
	Sulfated or worn out batteries	• Check specific gravity and electrolyte level of each battery.
	Dead Battery	• Charge battery.

If you cannot correct problems with these procedures, see your Northern Lights dealer.

### Lamp Flashing Pattern when Error has Occurred

Before starting the engine:

- 1. Check all connections before powering the Engine ECU on.
- 2. When the Engine ECU is powered on (assuming no failures), the lamp will flash one time and then off.
- 3. If an Engine ECU failure is detected, the lamp will flash one of the codes below.
- 4. To resolve an Engine ECU failure, turn power off, check and connect wiring connections and power on again.

Figure 16: Lamp Codes


Lamp Code	Reason For Error	Error Dectection	After Error Detection
13	Oil pressure SW failure or wire disconnected	Engine ECU Power ON (EG Start Enable)	Go to Low Power Mode
22	Pressure Sensor failure or wire disconnected	Engine ECU Power ON (EG Start Enable)	Go to Low Power Mode Go to Low Power Mode
33	Pressure Sensor failure or wire disconnected	Engine running Engine ECU Power ON (EG Start Enable)	Go to Low Power Mode Go to Low Power Mode
1.5		Engine running	Go to Low Power Mode
15	Speed Sensor Failure or wire disconnected	Cranking Engine Running	Engine doesn't start Go to Low Power Mode
04	Actuator drive wire disconnected	Engine ECU Power ON	Lamp action only
		Cranking	Engine doesn't start

### **Lamp Code Analysis**

Lamp Code specifies the pattern of long and short flashes the ECU uses to indicate a particular problem. The lamp will continue flashing as shown below until the error is resolved.


Case 1. Error Only:

Code: 13: Long, Short, Short, Short



Case 2. Error combination (when 2 errors occur at the same time):

Code 13: 13 means Long, Short, Short, Short Code 04: 04 means Short, Short, Short, Short



1 Cycle

# **ENGINE**

PROBLEM	POSSIBLE CAUSE	RECOMMENDATION(S)
Engine Hard to Start or Will Not Start	Improper starting procedure	• See starting section of this manual. Take special note of Bypass Switch operation.
	No fuel	• Check level of fuel in fuel tank.
	Low battery output	• Check electrolyte level and condition.
	Excessive resistance in starting circuit	Clean and tighten all battery connections.
	Crankcase oil too heavy	• Use oil of proper viscosity.
	Improper type of fuel	• Consult fuel supplier and use proper type of fuel for operating condition.
	Water, dirt or air in fuel system	• Drain, flush, fill and bleed system.
	Clogged primary or secondary fuel filter element	• Clean or replace primary filter element, replace secondary filter element.
	Dirty or faulty injection nozzles	• Have your dealer check injection nozzles.
	Fuel injected but no ignition	<ul><li> Glow plug malfunction.</li><li> Injection timing not correct.</li><li> Low cylinder compression pressure.</li></ul>
Engine Runs Irregularly	Below normal engine temperature	Remove and check thermostat.
or Stalls Frequently	Clogged primary or secondary fuel filter element	• Clean or replace primary filter element, replace secondary filter element.
	Water or dirt in the fuel system	• Drain, flush, fill and bleed system.
	Dirty or faulty injection nozzles	• Have your dealer check injection nozzles.
	Air in fuel system	• Inspect clamps and hoses on suction side of fuel pump for air leak.
	Improper type of fuel	• Consult fuel supplier and use proper type of fuel for operating condition.
	Low idle, not stable	• Uneven compression cylinders.
Lack of Engine Power	Intake air restriction	Service air cleaner.
	Clogged primary or secondary fuel filter element	• Clean or replace primary filter element, replace secondary filter element.
	Improper type of fuel	• Consult fuel supplier and use proper type of fuel for operating conditions.
	Overheated engine	• See "Engine Overheats" in next category.
	Below normal engine temperature	• Remove and check thermostat.
	Improper valve clearance	• Reset valves. Best done by dealer.
	Dirty or faulty injection nozzles	<ul><li>Replace injectors. Best done by dealer.</li><li>See your local dealer.</li></ul>

## **ENGINE**


PROBLEM	POSSIBLE CAUSE	RECOMMENDATION(S)
Lack of Engine Power (continued)	Cylinder compression pressure low, cylinder compression pressure leakage	<ul><li>Adjust valve clearance.</li><li>Adjust nozzle holder alignment.</li><li>Check cylinder bore wear.</li></ul>
Engine Overheats	Low coolant level or cooling system defective	<ul> <li>Fill tank or radiator to proper level.</li> <li>Check hoses for loose connections and leaks.</li> <li>Fan belt slipping.</li> </ul>
	Cooling system needs flushing	• Flush cooling system.
	Defective thermostat	• Remove and check thermostat.
	Defective temperature gauge	• Check water temperature with thermomete and replace gauge if necessary.
	V belts slipping	• Fix belts to proper tension.
Engine Knocks	Insufficient oil	• Call your dealer.
	Injection pump out of time	• Call your dealer.
	Below normal engine temperature	<ul><li>Check your thermostats.</li><li>Check water temperature to see if temperature gauge is working properly.</li></ul>
	Engine overheating	• See "Engine Overheating" section.
High Fuel Consumption	Improper type of fuel	• Use correct fuel for temperature.
	Clogged or dirty air cleaner	• Service air cleaner.
	Improper valve clearance	• See your dealer.
	Injection nozzles dirty	• See your dealer.
	Injection pump timing off	• See your dealer.
	Engine overloaded	• Check load usage.
	Engine not at proper temperature	<ul><li>Check your thermostats.</li><li>Check water temperature with thermometer and replace gauge if necessary.</li></ul>
Below Normal	Thermostats not working properly	• Check thermostats.
Engine Temperature	Temperature gauge not working properly	• Check water temperature with thermomete


If you cannot correct problems with these procedures, see your **Northern Lights** dealer.


# **ENGINE**


PROBLEM	POSSIBLE CAUSE	RECOMMENDATION(S)
Low Oil Pressure	Low oil level	• Fill crankcase to proper level.
	Clogged filter and strainer or worn bearings and oil pump	• Repair or replace.
	Improper type of oil	• Drain and fill crankcase with correct oil.
	Partially plugged oil filter	• Replace filter.
High Oil Consumption	Break-in period	• Oil consumption decreases after break in.
	Crankcase oil too light	• Use proper viscosity oil.
	Oil leaks	<ul> <li>Check for leaks in lines around gaskets and drain plug.</li> </ul>
Engine Emits Black or Gray Exhaust Smoke	Clogged or dirty air cleaner	• Service air cleaner.
	Defective muffler (back pressure too high)	Have dealer check back pressure.
	Improper fuel	• Use correct fuel for temperature.
	Injection nozzles dirty	• See your dealer.
	Engine injection timing off	• See your dealer.
Engine Emits	Improper fuel	Use correct fuel for temperature.
White Smoke	Cold engine	<ul> <li>Warm up engine to normal operating temperature.</li> </ul>
	Defective thermostat	• Remove and check thermostat.
	Engine injection timing off	• See your dealer.


If you cannot correct problems with these procedures, see your **Northern Lights** dealer.


























# **Wiring Diagrams**





NOTES: 1. All installation conductors are to be awg 14, type mTW, 600Vac, 105°C, stranded, except as noted.

S-3C Wiring Diagram
12 Volt Drawing A-12616
Wing diagrams are subject to change without notice.





4420 14th Ave. NW., Seattle WA 98107

Tel: (206) 789-3880 • 1-800-762-0165 • www.northern-lights.com

Northern Lights and Lugger are registered trademarks of Northern Lights, Inc.
© 2015 All rights reserved. Litho USA.